

Canon WFT-E1 (A) Wireless File Transmitter

Network Support Guide

Apple Macintosh



Authored by Simon Adams Product Support Specialist Canon UK RCC December 05

Revision 1.0 © Canon 2006

Setting up the WFT-E1A on the Apple Macintosh

This document will take you through the process of setting up the WFT-E1A wireless file transmitter in conjunction with an Apple Macintosh

In this example we have used the following test specifications:

Canon Eos 1DS Mk II Camera Body Canon WFT-E1A Wireless File Transmitter D-Link DWL-122 USB Wireless Transmitter (Required for Ad Hoc or Infrastructure Mode) Netgear WG602 Wireless Access Point (Required for Infrastructure Mode) Macintosh dual 2.5 GHz G5 running OSX 10.4.3

Three Stages to Complete Setup

There are three stages to setting up the WFT-E1A with your Mac.

- 1. Setting up your Wireless Network on your computer
- 2. Setting up your FTP Server on your computer
- 3. Setting up your WFT-E1A to talk to your Wireless Network and FTP Server

Stage 1 - Setting up your Wireless Network on your computer

Stage 1 will involve installing a wireless transmitter on your Mac. Most transmitters come in the form of a USB "dongle" that is inserted into a spare USB port on your Mac. The "dongle" should come with a manufacturer's installation disk that installs the necessary drivers for the "dongle". Once your "dongle" has installed correctly you should see an entry in System Preferences usually under "Other" relating to your wireless dongle. If you are using an airport card, then your wireless card settings may appear elsewhere in System Preferences.

If you experience difficulties installing your wireless transmitter or Airport card on your Mac you should contact your manufacturer for assistance with its installation.

We will start the network set up with the assumption that you have installed your Mac's wireless transmitter (dongle) and it is working correctly.

In the first instance you need to decide if you are going to set the WFT-E1 (A) to talk directly to your Mac's wireless card (Ad Hoc) or whether you are going to use a wireless access point (Infrastructure).

Ad Hoc mode is useful for use outside with a laptop where an access point would be cumbersome; however as Ad Hoc mode uses the older 802.11b wireless transmission format you will only achieve a file transfer rate of up to 11Mbps. Using an Access point that is compatible with the 802.11g wireless transmission format allows you to transmit files at up to 54Mbps.

From the Apple menu navigate to System Preferences pane

To set up your Network to communicate with the WFT-E1 (A) select the Network Icon from the System Preferences pane.

If you are setting up in Ad Hoc Mode, select your adapter from the "Show" drop down menu, and select to configure the IP address manually.

Insert your selected IP address in the IP Address box, and set your subnet mask to 255.255.255.0

If you are using Ad Hoc mode you will not need to fill in the Router box.

	cation: RCCLIK	•	
L			
	Show: Ethernet Adaptor (en	2) •	
TCP/	IP PPPoE AppleTalk Pr	oxies Ethernet	
Configure IPv4:	Manually	•	
IP Address:	192.168.0.10		
Subnet Mask:	255.255.255.0		
Router:			
DNS Servers:			
Search Domains:			(Optional)
IPv6 Address:	fe80:0000:0000:0000:0211:9	5ff:fe8f:c2ff	
	Configure IPv6		?

Show All	٩	
Lo	Show: Ethernet Adaptor (en2)	
TCP/	IP PPPoE AppleTalk Proxies Ethernet	
Configure IPv4:	Manually +	
IP Address:	192.168.0.10	
Subnet Mask:	255.255.255.0	
Router:	192.168.0.227	
DNS Servers:		
Search Domains:		(Optional)
IPv6 Address:	fe80:0000:0000:0000:0211:95ff:fe8f:c2ff	
	Configure IPv6	?
Click the lock to p	revent further changes. Assist me	Apply Now

If you are using a router, fill in the routers IP address in the Router field.

You will need to take a note of the login details of your Mac to enter into the camera later, however the username and login will be slightly different than you use to log in to your Mac, so note the following carefully.

In the system Preferences Pane select "Accounts", and note the "Short Name" of your computer. This is the login you will use on the camera (not the Name field). The password you will use in the camera will be the same as you use to login to the Mac itself.

If you are using Ad Hoc Mode, then use the short name as the SSID in the camera. If you are using a router, then the SSID of the router will need to be used in the camera. *** Take note that all entries in the Mac's settings and those entered into the camera are case sensitive and must match exactly**

000					
Show All				Q	
My Account	Password	Picture	Login Items	Parental Controls	-
RCC UK Admin		Name:			1
Other Accounts	Short	Name:	ccuk		1
			Ch	ange Password)
				_	
	Addre	ss Book	Card: Open	s computer	
Login Options			o daminister en	scomparei	
+ -					
Click the lock to ma	ke changes.				?

You will need to switch on the FTP server on the Mac, which you can action by selecting the System Preferences Pane, and select the Sharing icon Click on Services and tick the FTP Access service. Ensure that FTP Access shows as On.

	Other compu	uters on your local subnet can access	
	your compu		
	Serv	ices Firewall Internet	_
Soloct	a convice to change its r	settings	
Select	a service to change its s	settings.	
On	Service	FTP Access On	
	Personal File Sharing	Stop	
	Windows Sharing		
	Personal Web Sharing	Click Stop to prevent users of other	
	Remote Login	computer using FTP applications.	
$\overline{\checkmark}$	FTP Access		
- A	Apple Remote Desktop		
	Remote Apple Events		
	Printer Sharing		
	Yarid		
Other p	eople can access your FTP s	server at ftp://192.168.0.10/ or browse for "RCCUK" by	
choosin	g Network from the Go mer	nu in the Finder.	6

You'll also need to forward port 21 through your firewall if it is on, select Firewall from the sharing screen and tick FTP Access.

Show All				Q	
Computer Name:	RCCUK Other computers on y your computer at RCC	your local su CUK.local	bnet can acce	Edit	
Firewall Off Start Click St ports of Allow: On C F F F F F F F F F F F F F F F F F F F	Services F art to prevent incomin ther than those enable Description Personal File Sharing Vindows Sharing Personal Web Sharing Remote Login – SSH TP Access Apple Remote Deskto Remote Apple Events Printer Sharing	Firewall Ig network c ed below.	ommunicatio	n to all services and New Edit Delete Advanced	
Click the lock to p	revent further chang	jes.			?

Full permissions need to be set so that the WFT-E1 (A) can access the FTP's file space and create folders and files sent from the camera. On your desktop double click your Macintosh Hard Drive. Highlight the user (in this case rccuk) and select Get Info from the menu bar

		Q	
Network Macintosh HD Desktop rccuk Applications Documents Movies Music Pictures	rccuk	Shared	
	. 2	2 items, 118.02 GB available	

Set All Ownership and Permissions to full read & write access, and apply this to enclosed items. **If you** do not also allow sub folder read and write permissions and allow the creation of folders, the folder structure that is created (a mirror of the structure that is written to the camera's CF card, i.e. A>DCIM>EOS1D101 etc...) will not be allowed and the transmission will fail.

▼ General:
Kind: Folder
Size: 10.52 GB on disk
(11,248,659,098 bytes)
Where: /Users
Modified: Today at 16:57
Locked
More Info:
▼ Name & Extension:
rccuk
Hide extension
Preview:
Ownership & Permissions:
You can Read & Write
▼ Details:
Owner: rccuk 🛟 🔒
Access: Read & Write
Group: rccuk *
Access: Read & Write 🗘
Others: Read & Write
Apply to enclosed items

Lastly you should check that you have your wireless transmitter (dongle) on the Mac set to the appropriate transmission method (Ad Hoc or Infrastructure). This can be done from the System Preferences menu and the Wireless Adapter tab. This may differ if you are using Airport. You should consult Apple for assistance with the Airport system.

With our D-Link wireless adapter, once the camera has been set up we have selected "Show my networks" and the properties tab will allow us to select Ad Hoc or Infrastructure mode. If the adapter is in the wrong mode to that set on the camera the two will not communicate. **Remember Ad Hoc for camera direct to computer, Infrastructure for camera to access point to computer.**

CAPTURES Capture Me	Show All				٩
	Current Wireless N	letwork			
My Networks	Network Name: 1	rccuk		Link State: Conne	cted
Connect Order rccuk	Network Type: I Signal Strength:	Peer-to-Peer		Channel: 2 (2.41	L7 GHz)
				Hide M	ly Networks
	Available Wireless	Networks			
	Name rccuk	Type Peer-to-Peer	Signal 100%	Channel 2 (2.417 GHz)	Privacy WEP
Connect					
Properties					
Remove					
Create	Start Scan			C C	onnect
	Wireless Adaptor	Settings			
		Radio	Advanced	Info	
	MAC Add	ress: 00:11:95:8F:	C2:FF		
	Primary Firmv	vare: 1.01.03.21			
	Secondary Firmy	vare: 1.07.01.00			
	Driver ver	sion: 1.3.1			
				Cancel	Apply

Stage 3 - Setting up the WFT-E1A using the WFT-E1A Utility

Load the utility from the Canon WFT-E1A disc.

In the first tab TCP/IP, select "Use the following IP address" and enter and IP address here which will identify the WFT-E1A to the network. Ensure this address is not used by any other network device. We have used 192.168.0.50 here. The subnet mask should be set to 255.255.255.0 as only the last set of numbers will change on the network.

If we are using Ad Hoc (Peer to Peer) mode there is no gateway, so set this to 0.0.0.0. If you are using a wireless router or access point then set the gateway to the IP address of the access point or router.

WFT-E1A Utility - [NPRO	FILE.NIF]	
ile Edit Help TCP/IP settings	FTP settings	Wireless LAN settings
-	1	
O Use DHCP server		
Use the following IP ad	dress	
IP address:	192 . 168 . 0 . 50	
Subnet mask:	255 . 255 . 255 . 0	
Gateway:	0.0.0.0	
Use DNS server		
DNS server:	0.0.0.0	
Protect settings	Read settings	Save settings
		Close

Authored by Simon Adams Product Support Specialist Canon UK RCC December 05

10

Select the FTP settings tab, here we will enter settings that match the FTP server settings we set up earlier on the Mac

The target server address should be should match the address of the Mac's wireless transmitter (dongle) in this case it is 192.168.0.10. The port number should match the port number we opened in the FTP server, in this case Port 21 (which is in fact the industry standard port for FTP transfers).

The server name should be left blank, as the Target Server IP address identifies the FTP server, and as the target folder is set from within the FTP server Filezilla itself, then you should specify / as the target folder which means "Root folder" in FTP terms. Leave passive mode off, and overwrite same file on if you want to

Use the login and password you noted from the accounts page earlier, in this case we are using the username (the Mac's short name) *rccuk* and the password for the machine. Ensure that you use the exactly the same characters, and ensure they are the same case, any mismatch in the username and password will result in the WFT-E1A issuing an error and failing to transmit its images.

a WFT-E1A Utility - [NPROF ile Edit Help	ILE.NIF]	
TCP/IP settings	FTP settings	Wireless LAN settings
Target server		
Address:	🛛 . 168 . 0 . 10	
Port No.:	21	
Server name:		
Target folder:		
🗖 Use passive mode		
🔽 Overwrite same file		
User		19 57
Login name: rcc	uk	
Login password:		
Proxy		
🗖 Use proxy		
Address:	0.0.0.0	
Port No.:	10021	
Server name:		
Protect settings	Read settings	Save settings
	2	Close

No proxy is needed here, and it is prudent to tick the "Protect Settings" box!

Now select the Wireless LAN settings tab.

In the SSID setting, you must enter the name of the actual computer you are connecting to (details of how to locate this are in the next step). Here our Mac account is named rccuk, but yours will definitely be called something different! For the connection method, if you are using Ad Hoc and not using a router then select the channel you wish to transmit on. In Ad hoc mode the channel used is defined by the WFT-E1A and the "dongle" in your Mac will change its channel automatically. No encryption is used here for simplicities sake, however if you do input security keys, they must match both in the Wireless Network Property Settings and the WFT-E1 exactly or communications will fail.

If you are using a router then set the connection method as Infrastructure and the SSID to the wireless access point or router's SSID

Finally save these settings to your CF card using a card reader / writer device connected to your Mac, ready to insert into the camera connected to the WFT-E1A

SSID:	rccuk	
Conn. Method:	Ad hoc 💌	
	Channel: 2	
Authentication/Encry	ption	
Authentication:	💿 Open System	
	C Shared Key	
	C WPA-PSK	
Encryption:	None	
	C WEP	
	C TKIP	
Key Format:	Character strings	
	C Hexadecimal number	
Key:		

Lastly you will need to load the settings file into your camera. Insert the CF card containing the .NIF file and load the settings into your camera as detailed on page 23-25 of the WFT-E1A manual.

After loading the settings you may need to switch off and on again both the camera and the WFT-E1 (A) for communications to take place.

The orange link light should blink a few times, disappear, then remain steady and the display should show the connected speed as in the picture below. This will usually be up to 11Mbps for Ad Hoc connections and 54Mbps for Infrastructure connections.



Files that are transmitted when a picture is taken on the camera will appear under the following path:

Macintosh Hard Disk > Users > [Your User i.e. rccuk] > A > DCIM > [Your Camera's File Folder i.e. EOS101]

Note that on the Macintosh platform you will need to refresh the folder with the pictures in to view the transmitted pictures on the Macintosh's screen.

That's it! Enjoy using the WFT-E1A!